

# Emanata





-425758  
emanata

flat plate with  
wide rim



**690017**  
6.5" <sup>(36)</sup>

**690022**  
8.9" <sup>(24)</sup>

**690024**  
9.4" <sup>(24)</sup>

**690026**  
10.2" <sup>(12)</sup>

**690029**  
11.3" <sup>(12)</sup>

**690032**  
12.4" <sup>(12)</sup>

**690017-425758**

**690022-425758**

**690024-425758**

**690026-425758**

**690029-425758**

**690032-425758**

deep plate  
with wide rim



**690124**  
9.3" 11.8 oz <sup>(24)</sup>

**690129**  
11.3" 17.0 oz <sup>(12)</sup>

**690124-425758**

**690129-425758**



deep coupe plate



**691324**  
9.5" (12)

**691324-425758**

**691329**  
11.4" (12)

**691329-425758**

oval platter with rim



**692018**  
7.0" x 5.2" (36)

**692018-425758**

oval coupe platter



**692233**  
13.0" x 9.5" (12)

**692233-425758**

**692237**  
14.6" x 10.7" (6)

**692237-425758**



**-425758**  
emanata

flat rectangular coupe



**692342**  
16.5" x 7.9" (12)

**692342-425758**

oval bowl



**696212**  
4.6" x 3.5" 6.1 oz (24)  
use with lid 696312  
use with underliner 692018

**696212-425758**

demitasse cup



**695159**  
2.5" 3.0 oz (36)  
use with lid 696409  
use with saucer 696819, 696909

**695159-425758**

mug



**695635**  
3.5" 11.8oz (24)  
use with saucer 696919, 696819

**695635-425758**

cup



**695176**  
3.5" 8.8 oz (36)  
use with saucer 696919

**695176-425758**

saucer



**696909**  
5.3" (36)

**696909-425758**

**696919**  
6.3" (36)

**696919-425758**

tea pot



**694340**  
7.6" x 5.0"  
13.5 oz (24)

**694340-425758**